

Hinged patio door handing

French doors & center-hinged doors with one fixed panel



START HERE
Stand OUTSIDE and face the door.

1 Find the panel that opens first.
2 Check its hinges and swing.

ACTIVE = OPENS FIRST

Top views • Always viewed from outside


FRENCH PATIO DOORS

Both panels can open. The active panel opens first; the passive panel is shown closed.



CENTER-HINGED PATIO DOORS

One panel opens; one stays fixed. The active panel hinges at the center post.



● HINGE POINT OF ACTIVE PANEL

Dashed line = active panel when closed

CHECK BEFORE YOU ORDER

Uses Therma-Tru / Reeb residential handing. Other brands may use different labels.
End-hinged and three-panel units also exist. Bring a photo or sketch to confirm your layout.